





O Discharge of LiPo Batteries Using Saltwater Electrolysis V.1

marshall.bennett1

¹USDA-ARS

1 Works for me Share

dx.doi.org/10.17504/protocols.io.14egn274mg5d/v1

marshall.bennett

ABSTRACT

Procedure developed using information gathered from the following sources: How To Dispose Of Lipo Batteries? - Standard Battery (standardbatteryinc.com)

<u>Discharging & Disposing of LiPo Batteries – HeliDirect Support Center (zendesk.com)</u>

https://www.researchgate.net/profile/Alireza-

Bazargan/publication/352042531_Discharge_of_lithium-

ion_batteries_in_salt_solutions_for_safer_storage_transport_and_resource_recovery/links/61ebe8f78d338833e3895d56/Discharge-of-lithium-ion-batteries-in-salt-solutions-for-safer-storage-transport-and-resource-recovery.pdf

DOI

dx.doi.org/10.17504/protocols.io.14egn274mg5d/v1

PROTOCOL CITATION

marshall.bennett 2022. Discharge of LiPo Batteries Using Saltwater Electrolysis. **protocols.io**

https://dx.doi.org/10.17504/protocols.io.14egn274mg5d/v1

LICENSE

This is an open access protocol distributed under the terms of the Creative Commons Attribution License, which permits unrestricted use, distribution, and reproduction in any medium, provided the original author and source are credited

CREATED

Oct 21, 2022

LAST MODIFIED

Oct 21, 2022



1

PROTOCOL INTEGER ID

71651

MATERIALS TEXT

- 1 sealable container with a vented lid, such as a five gallon bucket
- non-iodized salt
- filtered water
- sealable plastic bag large enough to fit battery
- 1 Place the battery into a container that is sealable with a vented lid, such as a five gallon bucket.
- Dissolve non-iodized salt into water in a bucket following the measurements outlined in the chart below.

- 3 Carefully pour the salt/water solution into the container holding the battery so that it is completely submerged and covered in several inches of water.
- 4 Check for activity from the battery and cover the bucket with the vented lid. Bubbles should emerge from the battery's terminal port as electrolysis begins.
- Monitor the battery and the lid regularly. It is possible that residue may develop along the surface of the salt/water solution, and it may take several changes of the water for the battery to completely discharge. Complete discharge of the battery could take many days, depending on the size and build of the battery.
- 6 Battery is safe to be recycled or disposed of when electrolysis is complete and voltage is at a low level. Store the battery in a sealable plastic bag until it is ready to be disposed of.