

VERSION 2 DEC 06, 2023

OPEN BACCESS



DOI:

dx.doi.org/10.17504/protocol s.io.kxygx92rdg8j/v2

External link:

https://doi.org/10.1371/journ al.pone.0288264

Protocol Citation: M Purushotham Rao, Akshay Uttarkar, Vidya Niranjan 2023. Protocol for the development of coarsegrained structures for macromolecular simulation using GROMACS.

protocols.io

https://dx.doi.org/10.17504/p rotocols.io.kxygx92rdg8j/v2V ersion created by Vidya Niranjan © Protocol for the development of coarse-grained structures for macromolecular simulation using GROMACS V.2

PLOS One Peer-reviewed method

M Purushotham

Rao¹, Akshay Uttarkar¹, Vidya Niranjan¹

¹R V College of Engineering

PLOS ONE Lab Protocols

Spotlight series



Vidya Niranjan

ABSTRACT

This paper presents a protocol for the development of coarse-grained (CG) structures for macromolecular simulation using the GROMACS software. CG models are widely used in molecular simulations due to their computational efficiency, which allows for the study of large and complex systems. The protocol described here outlines the steps necessary for the creation of CG structures, including the selection of appropriate beads, mapping of the CG beads onto the atomistic structure, and the parameterization of the CG model. The protocol also includes guidelines for validating the accuracy of the CG model, as well as recommendations for future improvements in CG model development. The described protocol will be useful for researchers interested in the development of CG models for macromolecular simulations using GROMACS.

The last step contains a supplemental video with extra context and tips, as part of the protocols.io Spotlight series, featuring conversations with protocol authors.

GUIDELINES

Commands are indicated in bold letters

MATERIALS

https://drive.google.com/file/d/1YDJV2hKtZ5dJrl8S6A_4AFdTt_IVJFMv/view?usp=sharing

https://github.com/MPurushothamRao/miscellaneous https://drive.google.com/file/d/1if8nCmmOAXT-ZTEQGu2ctG3bcgaQayPi/view?usp=sharing

Oct 6 2023

MANUSCRIPT CITATION:

Niranjan V, Rao P, Uttarkar A, Kumar J (2023) Protocol for the development of coarsegrained structures for macromolecular simulation using GROMACS. PLOS ONE 18(8):

e0288264. https://doi.org/10.1371/journal.pone.0288264

License: This is an open access protocol distributed under the terms of the Creative Commons Attribution License, which permits unrestricted use, distribution, and reproduction in any medium, provided the original author and source are credited

Protocol status: Working We use this protocol and it's

working

Created: Dec 05, 2023

Last Modified: Dec 06,

2023

PROTOCOL integer ID:

91860

Keywords: Martini, Coarse grain, Molecular Simulation

SAFETY WARNINGS

Ensure all the requirements are satisfied for tools like Gromacs, Dssp.
If there are more warning while running gromas check for their impact, if its not harmful. Ignore it using maxwarn

BEFORE START INSTRUCTIONS

A basic understanding on gromacs and simulations. For visual assistance refer to https://youtu.be/QMR4f4eRSbs

DOWNLOAD NECESSARY PROTEIN

1 DOWNLOAD THE PDB FILE FROM https://www.rcsb.org/
Here, in this tutorial DUSP28 https://www.rcsb.org/structure/5Y15 is used.

Preprocess the pdb to remove all ions and B chain or can obtained from here

https://drive.google.com/file/d/1YDJV2hKtZ5dJrl8S6A_4AFdTt_IVJFMv/view?usp=sharing

DOWNLOAD NECESSARY SOFTWARE AND FILES

Martinize python script http://cgmartini.nl/index.php/tools2/proteins-and-bilayers/204-martinize
Martini itp file required version http://cgmartini.nl/index.php/force-field-parameters/particle-definitions
Martinin ions itp file http://cgmartini.nl/index.php/force-field-parameters/ions
Dssp Executable https://github.com/cmbi/dssp - use source 2.3 version dssp to ssd python script (Optional) https://github.com/MPurushothamRao/miscellaneous
Gromacs type this in terminal- sudo apt-get install gromacs

mdp files https://drive.google.com/file/d/1if8nCmm0AXT-ZTEQGu2ctG3bcgaQayPi/view?usp=sharing
https://cgmartini.nl/index.php/downloads/example-applications/63-pure-water-solvent

VMD https://www.ks.uiuc.edu/Development/Download/download.cgi?PackageName=VMD

XMGRACE type this in terminal- sudo apt-get install grace

Commands shell script https://github.com/MPurushothamRao/miscellaneous

COARSE GRAINING OF PROTEIN

3 change dssp executable path and required force field and use python3 martinize.py -h for help python3 martinize.py -f 5y15_processed.pdb -o single-5y15.top -x 5y15-CG.pdb -dssp /usr/local/bin/mkdssp -p backbone -ff martini22

or use ssd file as input

mkdssp-i 5y15.pdb-o 5y15.dssp

to conver dssp file to ssd file

python3 dssp2ssd.py -i 5y15.dssp -o 5y15.ssd

python3 martinize.py -f 5y15_processed.pdb -o single-5y15.top -x 5y15-CG.pdb -ss 5y15.ssd -p backbone -ff martini22

Here we have used second method.

```
(base) rvce-bt-06@rvcebt06-HP-280-G3-MT:-/Desktop/purushothan_bbt21/single_chei$ mkdssp -i 1UBQ.pdb -o 1UBQ.dssp (base) rvce-bt-06@rvcebt06-HP-280-G3-MT:-/Desktop/purushothan_bbt21/single_chei$ python3 dssp2ssd.py -i 1UBQ.dssp -o 1UBQ.ssd (base) rvce-bt-06@rvcebt06-HP-280-G3-MT:-/Desktop/purushothan_bbt21/single_chei$ python martinize.py -f 1UBQ.pdb -o single-ubq.top -x 1UBQ-CG. pdb -ss 1UBQ.ssd -p backbone -ff martiniz2 and purushothan_bbt21/single_chei$ python martinize.py -f 1UBQ.pdb -o single-ubq.top -x 1UBQ-CG. pdb -ss 1UBQ.ssd -p backbone -ff martiniz2 and purushothan_bbt21/single_chei$ python martinize.py -f 1UBQ.pdb -o single-ubq.top -x 1UBQ-CG. pdb -ss 1UBQ.ssd -p backbone -ff martiniz2 and purushothan_bbt21/single_chei$ python martinize.py -f 1UBQ.pdb -o single-ubq.top -x 1UBQ-CG. pdb -ss 1UBQ.ssd -p backbone -ff martiniz2 and purushothan_bbt21/single_chei$ python martinize.py -f 1UBQ.pdb -o single-ubq.top -x 1UBQ-CG. pdb -s 1UBQ.ssd -p backbone -ff martiniz2 and purushothan_bbt21/single_chei$ python martinize.py -f 1UBQ.pdb -o single-ubq.top -x 1UBQ-CG. python martinize.py -f 1UBQ.des -python python pyth
```

Output of Martinizing (Coarse graining) of the protein

4 to change name of martini itp file in toplogy, for what you have selected in above step sed -i -e 's/martini.itp/martini_v2.2.itp/' single-ubq.top

Snap of topology file after above command

SYSTEM SETUP

5 Setup Periodic box

gmx editconf -f 1UBQ-CG.pdb -o 1UBQ-CG.gro -d 1.0 -c -bt dodecahedron

```
Command line:
gmx editconf -f 1UBQ-CG.pdb -o 1UBQ-CG.gro -d 1.0 -c -bt dodecahedron

Note that major changes are planned in future for editconf, to improve usability and utility.

Read 163 atoms

Volume: 62.9497 nm^3, corresponds to roughly 28300 electrons

No velocities found
system stze: 2.763 2.966 3.382 (nm)
diameter : 4.224 (nm)
center : 2.999 2.891 1.522 (nm)
box vectors: 5.084 4.277 2.895 (nm)
box angles: 90.80 90.80 90.80 90.800 (degrees)
box volume: 62.95
shift : 1.670 1.778 0.679 (nm)
new center : 4.668 4.668 2.201 (nm)
new dox vectors: 6.224 6.224 6.224 (nm)
new box angles: 60.00 60.00 90.00 (degrees)
new box volume : 170.53 (nm^3)

GROMACS reminds you: "I don't want to achieve immortality through my work... I want to achieve it through not dying!" (Woody Allen)
```

Output after addition of Box

- To minimise the coarse_grained structure in vaccum

 gmx grompp -f em_vac.mdp -c 1UBQ-CG.gro -p single-ubq.top -o em_vac.tpr
- 6.1 gmx mdrun -deffnm em_vac -v

```
Step= 100, Dmax= 7.2e-03 nm, Epot= -3.21980e+03 Fmax= 4.83235e+02, atom= 56
Energy minimization reached the maximum number of steps before the forces
reached the requested precision Fmax < 10.

writing lowest energy coordinates.

Steepest Descents did not converge to Fmax < 10 in 101 steps.
Potential Energy = -3.2234973e+03
Maximum force = 1.3524817e+02 on atom 63
Norm of force = 3.5189513e+01

GROMACS reminds you: "Stay Cool, This is a Robbery" (Pulp Fiction)
```

After energy minimization in Vacuum

7 Solvate the protein gmx solvate -cp em_vac.gro -cs water.gro -radius 0.21 -o solvated.gro

7.1 To add number of water molecules into toplogy file for polarised water divide count by 3 cp single-ubq.top system.top count=\$(grep -c "W" solvated.gro | tr -d '\n') echo -e "\nW \$count" >> system.top

```
Generating solvent configuration
Will generate new solvent configuration of 2x2x2 boxes
Solvent box contains 1926 atoms in 1926 residues
Removed 643 solvent atoms due to solvent-solvent overlap
Removed 117 solvent atoms due to solvent-solvent overlap
Sorting configuration
Found 1 molecule type:

W (1 atoms): 1166 residues
Generated solvent containing 1166 atoms in 1166 residues
Writing generated configuration to solvated.gro

Output configuration contains 1329 atoms in 1242 residues
Volume : 170.528 (nm²3)
Density : 2122.5 (g/l)
Number of solvent molecules: 1166

GROMACS reminds you: "Hangout In the Suburbs If You've Got the Guts" (Urban Dance Squad)

(base) rvce-bt-06@rvcebto6-HP-280-G3-NT:-/Desktop/purushotham_bbt21/single_ches$ cp single-ubq.top system.top
(base) rvce-bt-06@rvcebto6-HP-280-G3-NT:-/Desktop/purushotham_bbt21/single_ches$ count-5(grep - c "W" solvated.gro | tr -d '\n')
(base) rvce-bt-06@rvcebto6-HP-280-G3-NT:-/Desktop/purushotham_bbt21/single_ches$ count-5(grep - c "W" solvated.gro | tr -d '\n')
```

Addition of water molecules and making system topology files

Add ions (optional to neutralise or addition ions)

gmx grompp -f ions.mdp -c solvated.gro -p system.top -o ions.tpr

gmx genion -s ions.tpr -o ions.gro -p protein.top -pname NA+ -nname CL- -conc 0.1 -neutral

we have not added here but in the video its shown how to add.

SIMULATION

- 9 Energy minimisation
 - gmx grompp -f em.mdp -c solvated.gro -r solvated.gro -p system.top -o em.tpr -maxwarn 1 maxwarn is because there is an mismatch of atom names but all the atoms are present
- 9.1 gmx mdrun -deffnm em -v

```
Step= 72, Dnax= 8.3e-03 nm, Epot= -3.53527e+04 Fmax= 2.39550e+02, atom= 63
Step= 73, Dnax= 1.0e-02 nm, Epot= -3.53558e+04 Fmax= 6.22100e+02, atom= 63
Step= 76, Dnax= 7.2e-02 nm, Epot= -3.53558e+04 Fmax= 6.4114e+02, atom= 65
Step= 76, Dnax= 7.2e-03 nm, Epot= -3.53360e+04 Fmax= 2.49495e+02, atom= 63
Step= 77, Dnax= 8.0e-03 nm, Epot= -3.53806e+04 Fmax= 2.49495e+02, atom= 63
Step= 78, Dnax= 1.0e-02 nm, Epot= -3.53806e+04 Fmax= 3.82917e+02, atom= 63
Step= 78, Dnax= 1.0e-02 nm, Epot= -3.53961e+04 Fmax= 3.82917e+02, atom= 63
Step= 80, Dnax= 1.5e-02 nm, Epot= -3.54069e+04 Fmax= 5.06277e+02, atom= 63
Step= 80, Dnax= 1.5e-02 nm, Epot= -3.54259e+04 Fmax= 7.56511e+02, atom= 63
Step= 83, Dnax= 1.1e-02 nm, Epot= -3.54259e+04 Fmax= 7.58939e+02, atom= 63
Step= 86, Dnax= 7.7e-03 nm, Epot= -3.544259e+04 Fmax= 7.58939e+02, atom= 63
Step= 86, Dnax= 7.7e-03 nm, Epot= -3.54531e+04 Fmax= 3.66406e+02, atom= 63
Step= 88, Dnax= 1.1e-02 nm, Epot= -3.54629e+04 Fmax= 3.66406e+02, atom= 63
Step= 88, Dnax= 1.1e-02 nm, Epot= -3.54629e+04 Fmax= 5.33631e+02, atom= 63
Step= 89, Dnax= 1.1e-02 nm, Epot= -3.54629e+04 Fmax= 5.53263e+02, atom= 63
Step= 89, Dnax= 1.1e-02 nm, Epot= -3.54629e+04 Fmax= 5.53263e+02, atom= 63
Step= 91, Dnax= 8.0e-03 nm, Epot= -3.54629e+04 Fmax= 5.53263e+02, atom= 63
Step= 93, Dnax= 1.1e-02 nm, Epot= -3.54629e+04 Fmax= 5.8388e+02, atom= 65
Step= 93, Dnax= 1.1e-02 nm, Epot= -3.54629e+04 Fmax= 5.8388e+02, atom= 66
Step= 93, Dnax= 1.1e-02 nm, Epot= -3.54629e+04 Fmax= 5.8388e+02, atom= 66
Step= 99, Dnax= 1.2e-02 nm, Epot= -3.55167e+04 Fmax= 3.9374e+02, atom= 63
Step= 99, Dnax= 1.1e-02 nm, Epot= -3.55167e+04 Fmax= 3.9374e+02, atom= 63
Step= 99, Dnax= 1.1e-02 nm, Epot= -3.55167e+04 Fmax= 5.81378e+02, atom= 63
Step= 99, Dnax= 1.1e-02 nm, Epot= -3.55167e+04 Fmax= 5.81378e+02, atom= 63
Step= 99, Dnax= 1.2e-02 nm, Epot= -3.55167e+04 Fmax= 5.81378e+02, atom= 63
Step= 99, Dnax= 1.2e-02 nm, Epot= -3.55167e+04 Fmax= 5.81378e+02, atom= 63
Step= 99, Dnax= 1.2e-02 nm, Epot= -3.55167e+04 Fmax= 5.81356e+02, atom= 63
Step= 99, Dnax= 1.2e-02 nm
```

Energy Minimisation

10 NVT equilibration

gmx grompp -f nvt.mdp -c em.gro -r em.gro -p system.top -o nvt.tpr

10.1 gmx mdrun -deffnm nvt -v

NVT equilibration for 20ns

11 NPT equilibration

gmx grompp -f npt.mdp -c nvt.gro -r nvt.gro -p system.top -o npt.tpr

11.1 gmx mdrun -deffnm npt -v

```
1000000 steps, 20000.0 ps.
step 999900, remaining wall clock time: 0 s
Writing final coordinates.
step 1000000, remaining wall clock time: 0 s
Core t (s) Wall t (s) (%)
Time: 544.539 136.135 400.0
(ns/day) (hour/ns)
Performance: 12693.311 0.002

GROMACS reminds you: "Do the Dog On the Ground" (Red Hot Chili Peppers)
```

NPT equilibration for 20ns

12 MD run

gmx grompp -f md.mdp -c npt.gro -p system.top -o md.tpr

12.1 gmx mdrun -deffnm md -v

```
Compiled SIMD: SSE4.1, but for this host/run AVX2_256 might be better (see
Reading file md.tpr, VERSION 2021.4-Ubuntu-2021.4-2 (single precision)
Changing nstlist from 20 to 25, rlist from 1.218 to 1.267
Using 1 MPI thread
Using 4 OpenMP threads
starting mdrun 'Martini system from 1UBQ.pdb'
10000000 steps, 200000.0 ps.
step 9999900, remaining wall clock time:
Writing final coordinates.
step 10000000, remaining wall clock time:
                                                         0 s
                  Core t (s) Wall t (s)
5309.617 1327.404
                                                          (%)
         Time:
                                                       400.0
                     (ns/day)
                                    (hour/ns)
Performance:
                    13017.890
                                         0.002
GROMACS reminds you: "It Was My Pleasure" (Pulp Fiction)
```


Production run for 200 ns

ANALYSIS

13 Analysis

Before analysis conect command should be used to show bonds in visualisation software and also pbc should be removed


echo 1 1 | gmx trjconv -f md.gro -s md.tpr -o recentered_traj.gro -pbc mol -center echo 1 | gmx trjconv -f recentered_traj.gro -s md.tpr -conect -o connected_traj.pdb echo 1 1 | gmx trjconv -f md.xtc -s md.tpr -o recentered_traj.xtc -pbc mol -center sed -i '/ENDMDL/d' connected_traj.pdb to visualize vmd recentered_traj.xtc connected_traj.pdb



Video shows protein over 20ns

13.1 Calculation RMSD and radius of Gyration and plotting using XMGRACE

echo 1 1 | gmx rms -s md.tpr -f recentered_traj.xtc -o rmsd.xvg xmgrace rmsd.xvg echo 1 | gmx gyrate -s md.tpr -f recentered_traj.xtc -o gyrate.xvg xmgrace gyrate.xvg



RMSD plot Distance nm vs Time ps

- 14 Step 2- 12 can be automated using a shell script sh commands.sh
- Video of tutorial https://youtu.be/QMR4f4eRSbs

Spotlight video

16

h