



APR 09, 2024

Smell discrimination test

daniel.dautan daniel¹, Per Svenningsson¹

¹Karolinska Institute

ASAP Collaborative Research Network

Kapliitt Protocols



Eileen Ruth Torres
Weill Cornell Medicine

ABSTRACT

Behavioral test to assess smell discrimination in mice.

MATERIALS

- Chocolate pellets (Bio Serv F05301)
- Trimethylthiazoline (TMT) (Sigma Aldrich 13623-11-5)

OPEN ACCESS



DOI:

dx.doi.org/10.17504/protocols.io.36wgq3wwxlk5/v1

Protocol Citation: daniel.dautan daniel, Per Svenningsson 2024. Smell discrimination test.

protocols.io

<https://dx.doi.org/10.17504/protocols.io.36wgq3wwxlk5/v1>

License: This is an open access protocol distributed under the terms of the [Creative Commons Attribution License](#), which permits unrestricted use, distribution, and reproduction in any medium, provided the original author and source are credited

Protocol status: Working

We use this protocol and it's working

Created: Feb 21, 2024

Last Modified: Apr 09, 2024

PROTOCOL integer ID: 95566

Keywords: ASAPCRN, odor discrimination

Funders Acknowledgement:

Aligning Science Across
Parkinson's
Grant ID: 020608

- 1 Transfer the cage into the experimental room at least 1h before testing. Always maintain the cage in a ventilated cage rack to avoid smell contamination.

- 2 Set the open field before starting experiment. The open field is a dark-grey box of 40 x 40 cm with clean floor and a light suspended above the center. A maximum of 150 lux is display to avoid excessive stress. The experiment need to be done in a highly ventilated room.

- 3 At a randomly selected corner, place the 8cm plexiglass cylinder which has holes on the side.

- 4 Always start with the positive smell as the TMT smell might affect further experiments.

- 5 Before the test place ~10 chocolate flavor pellets (Bio Serv F05301) into the plexiglass cylinder.

- 6 Transfer the mice into the center of the open field using a paper tube.

- 7 Record the mice's positions for 20 minutes using tracking software, such as Ethovision XT or AnyMaze.
- 8 At the end of the test, remove the mice from the apparatus. Remove the cylinder and clean the apparatus with 50% ethanol before proceeding to the next animals.
- 9 On the following day, repeat the experiment but this time the cylinder needs to be placed in a different corner.
- 10 In the cylinder place a cotton ball that was covered with ~20µl of 5% TMT solution (Sigma Aldrich 13623-11-5), in water.
- 11 Place the mice in the center of the open field and record positions for 20 min.
- 12 Clean thoroughly the cage after each experiment with 50% ethanol.
- 13 Using the tracking software extract:
 - a) distance travelled for 20 min
 - b) average speed
 - c) time in the center of the apparatus
 - d) time in the corner paired with the smell
- 14 Using each value, compare the time spent in chocolate or TMT corner and the ratio correspond to the olfactory discrimination index.

